



SECTION

NOTES:

1. DO NOT SET TEST STATION IN ROADWAY. PLACE TEST BOX IN NON-PAVED AREA NEXT TO ROADWAY.
2. RUN ALL WIRES IN 2" PVC SCH. 40 CONDUIT FROM CONNECTION POINT UNTIL THEY REACH THE BOTTOM OF TEST STATION ASSEMBLY.
3. FOR WIRE TYPE AND SIZES, SEE DETAIL C/2.2.
4. FOR PLAN AND ELEVATION VIEWS, SEE DETAIL C/2.0 AND C/2.2a.
5. FOR WIRE TYPE AND SIZES SEE DETAIL C/2.2, C/2.5, C/3.0, C/3.0b, C/3.0c, C/3.1, C/3.2, C/3.4, C/4.5, C/4.6 AND C/4.7.

WASHINGTON
SUBURBAN
SANITARY
COMMISSION

APPROVED: 5-26-21
Mike Hammer
Chief Engineer

STANDARD DETAIL
TYPICAL
TEST STATION INSTALLATION

C
2.2b