



**NOTES:**

1. THE TEST LEAD WIRES SHALL BE STRANDED COPPER AWG WIRE WITH TW, THW, OR THWN
2. RUN ALL WIRES IN 2" PVC SCH. 40 FROM THE CONNECTION POINT UNTIL THEY REACH THE BOTTOM OF TEST STATION ASSEMBLY.
3. FOR PCCP x DIP TIE-IN FITTINGS AND ASSEMBLY, SEE DETAIL C/3.3.
4. AFTER INSTALLATION AND ASSEMBLY, TEST INSTALLING JOINT.

WASHINGTON  
SUBURBAN  
SANITARY  
COMMISSION

APPROVED: 7-26-21  
*Mike Hammer*  
Chief Engineer

STANDARD DETAIL  
PCCP x DIP  
TIE - IN DETAIL  
WITH INSULATING JOINT  
AND TEST LEAD WIRES

C  
3.4