



POLYETHYLENE PIPE INSTALLATION ONLY

NOTES:

1. WHERE TEST STATION IS NOT DIRECTLY OVER PIPELINE, USE DETECTABLE WARNING TAPE (YELLOW) OVER TEST WIRES, SEE SPECIFICATIONS.
2. LOCATE TEST STATION OUTSIDE OF PROPOSED OR EXISTING PAVED AREAS
3. RUN ALLS WIRES IN 2" PVC SCH. 40 FROM THE CONNECTION POINT UNTIL THEY REACH THE BOTTOM OF THE TEST STATION ASSEMBLY.

WASHINGTON
SUBURBAN
SANITARY
COMMISSION

APPROVED: 7-26-21
M. H. Harn
Chief Engineer

STANDARD DETAIL
PIPE MOUNTED ABOVE
GROUND
TEST STATION

C
4.2