

NOTES:

- 1. INSTALL ANODES A MINIMUM OF 12 INCHES FROM PIPE.
- 2. BACKFILL ANODES WITH NATIVE SOIL FOR A MINIMUM OF 12 INCHES ON ALL SIDES. DO NOT BACKFILL ANODES WITH SAND OR STONE.
- 3. DO NOT THERMITE WELD TO PVC PIPE.

WASHINGTON
SUBURBAN
SANITARY
COMMISSION

APPROVED: 7-26-21

STANDARD DETAIL

PVC MAIN
SINGLE ANODE PLACEMENT

7.13