



PLAN VIEW
NO SCALE

NOTES:

1. SEE DETAIL C/1.0 FOR BOND WIRE SIZE AND INSULATION.
2. PROVIDE SLACK IN WIRES AND FASTEN TO MANHOLE TO PROTECT WIRES FROM DAMAGE.
3. FOR USE WHEN WIRES NEED TO BE ROUTED AROUND AIR RELEASE MANHOLES, SEWER MANHOLES, OR OTHER CIRCULAR STRUCTURES.

WASHINGTON
SUBURBAN
SANITARY
COMMISSION

APPROVED: 7-26-21
Mike Hammer
Chief Engineer

STANDARD DETAIL
DUCTILE IRON PIPE
BONDING AROUND
MANHOLE

C
1.3a