

WIRING SCHEDULE					
DESCRIPTION	WIRE	TEST STATION TERMINAL	AWG WIRE SIZE	TYPE OF INSULATION	COLOR OF INSULATION
NEW WATER MAIN	A B	1 3	#12 #6	THWN THWN	BLACK BLACK
PERMANENT REFERENCE ELECTRODE	С	6	PER MANUFACTURER	PER MANUFACTURER	PER MANUFACTURE
PREPACKAGED MAGNESIUM ANODE LEAD	D1 D2	N/A	#12 #12	THW, THWN OR THHN	WHITE WHITE
MAGNESIUM ANODE HEADER CABLE	D3	4	#8	HMWPE	BLACK

NOTES:

- 1. INSTALL 0.01 OHM SHUNT BETWEEN TERMINALS #1 AND #4.
- 2. MAINTAIN SUFFICIENT SLACK IN THE TEST WIRES SO THAT THE WIRES CAN EXTEND A MINIMUM OF 18 INCHES FROM THE TEST BOX.
- 3. BOND ALL DUCTILE IRON COMPONENTS TOGETHER WITH AWG NO. 6 HMWPE WIRES.
- 4. INSTALL BOND WIRES ON TOP OF PIPE OR FITTING WHERE POSSIBLE.
- 5. INSTALL A MINIMUM OF TWO BOND CABLES ACROSS EACH PIPE JOINT.
- 6. SEE WSSC STANDARD DETAIL C/1.2 FOR BONDING OF VALVE.
- 7. INSTALL BOND CABLES ON HYDRANT RISER PIPE AND ELBOW BEFORE INSTALLING FIRE HYDRANT.
- 8. RUN ALL WIRES IN 2" PVC SCH. 40 CONDUIT FROM CONNECTION POINTS UNTIL THEY REACH THE BOTTOM OF TEST STATION ASSEMBLY.

WASHINGTON
SUBURBAN
SANITARY
COMMISSION

APPROVED: 7-26-2 | STANDARD DETAIL

HYDRANT TEST STATION
(TYPE C)

Chief Engineer